



**SBW (Seatbelt Warning System)**  
(when installed)

Near Low fuel lamp	1	W
PASS. SEAT	2	O
PASS. SEAT BELT	3	Y
To F4	4	NR
DRIVERS SEAT	5	S
DRIVERS SEAT BELT	6	K
Near Low fuel lamp	7	OLG
To F3	8	GO
	9	B
To buzzer door sw.	10	PG
To ign. sw.	11	WY
To starter sol.	12	WY

- COLOR CODE**
- B - BLACK
  - U - BLUE
  - R - RED
  - W - WHITE
  - N - BROWN
  - P - PURPLE
  - Y - YELLOW
  - L - LIGHT
  - G - GREEN
  - K - PINK
  - S - SLATE
  - O - ORANGE
- SYMBOLS**
- SWITCH
  - LAMP
  - FUSE
  - SNAP CONNECTOR
  - BONNET CONNECTOR
  - PLUG AND SOCKET
  - GROUND CONNECTION
  - SBW SYSTEM CONNECTION